



Push Pad Installation Guide

Self-cleaning Alcohol Gel Door Push Pads

engineered to:
KILL germs in the **vital SECONDS** between **ONE user & the NEXT** passing through the **door**, to help **STOP** the **spread of germs**

Proven to increase hand washing & gel dispenser usage & **QUICK & easy** to Install

how it works:
Surfaceskins self-clean in **SECONDS** via secretion of Alcohol gel to the top surface when pressed by the user

Prior to use



The system comprises of holsters to attach to the door and sealed pouches (each containing one Push Pad) which snap fits into the holster. (Note: Push pads to be regularly changed. Holsters do not require changing unless damaged).



Make sure the Push Pads are stored in the correct orientation, (each box and pouch has arrows), this will ensure optimal performance from the moment the Push Pads are installed.



To maximise their active life, do not open the pouch until you are ready to install. Products come fully primed ready for use. (For more information on this primed state, please refer to the **Operating Mode of Action** information).

Installation of holster



Select the push-plate area or an area of the door with a flat uniform surface. If desired, wipe clean the area where you will attach the holster to ensure the best adhesion.



Prepare the holster for fixing to the door by removing the protective film from the adhesive stickers on the reverse of the holster.



Position the holster at your preferred location on the door and apply firm pressure to the top, middle and bottom to activate the adhesive, fixing the holster to the door.

Installation of pushpads



Open the pack by tearing downward from the notch at the top right of the pouch or from the back and remove the Push Pad.



The Push Pads come fully primed, so there may be a small amount of gel on the surface of the film. This is normal and ensures the Push Pad is active from the moment of installation.



Push the Push Pad into the holster until a positive click is felt and the edge of the Push Pad is flush with the holster.



The door Push Pad is now ready for use. Please push it as you would a regular door plate to open the door.



A small amount of active solution will be released as you push the surface of the Push Pad.



This self-cleans the contacted area in **SECONDS**, ready for the next person.

Shortly after installation excess gel may occasionally be released during use. Continue using the pushpad as normal and it will soon self-regulate to reach its normal operational state.

(Refer to the **Operational Mode of Action** for more Information on the primed and operational states).

Cleaning & removal of pushpads



The products are wipe-able and can be included in your normal cleaning regime if required. Simply wipe the surface as you would a regular door plate.



At the end of the active life of the pushpad, remove the pushpad from the holster by inserting a finger into the holster indentation (located top right and left of the holster) and pull out the old exhausted Push Pad.



Fit the holster with a fresh pushpad, as you did initially, to provide another period of user protection.

(Recommended 1000 activations).